


SB-E-8-305 ISS.05

CE

OPERATION MANUAL DVFR-1 Air Filter Regulator







CE

Operation Manual DVFR-1 Air Filter Regulator Important

Read and follow all instructions and Safety Precautions before using this equipment

Description

A compact Air Filter Regulator suitable for 1 or 2 operators, designed to remove entrained dirt, liquid oil and water from flowing compressed air, and to regulate the air pressure to enable air using devices to be operated.

Regulator is a self relieving design that senses over-pressure at the regulated outlets and vents excess pressure to atmosphere. The rolling diaphragm improves pressure sensitivity adjusting the valve for fluctuating airflows and pressures.

Model


Order No. DVFR-1 Filter regulator unit. Complete with air pressure gauge and mounting bracket.

Specifications

Air supply connection Air outlet connections Gauge port Size width height	1/2" BSP female. 1/4" BSP male. 1/8" BSP female. 175 mm 280 mm
Weight	2.5 kg
Maximum: air flow air supply pressure regulated air pressure operating temperature	3550 l/min 13 bar 0-8 bar 100° C
Filter aperture size	5 micron
Typical pressure drop	0.75 bar

Parts List

Ref No	Part No	Description
1	DV-9450806	Upper Cover Assembly including diaphragm
2	DV-9451705	Replacement Filter Element (5 microns)
3	DV-9453301-MET	Metal Filter Bowl with drain valve
4	SER-3414-MF	Ball Valve 1/4 inch BSP (m) & (F)
5	GA-319	Pressure Gauge 0-160 psi
6	DV-8000035	Isolation Valve



▲ SAFETY WARNINGS



Misuse

- Never exceed the recommended safe working pressure/temperature for any of the equipment used.
- Do not use paint solvents to clean the unit or filter element.
- The fitting of non- recommended or non- original accessories or spare parts may create hazardous conditions.
- Do not install the unit above electrical or any other equipment that will be damaged by discharged condensate.
- Before dismantling the equipment for cleaning or maintenance, all air pressures must be isolated and released.
- When assembling an air pressure gauge to the unit DO NOT use a spanner, always tighten by hand.
- The disposal of non-metallic materials must be carried out in an approved manner. Burning may generate toxic fumes.

Installation / operation

- 1. Always install the unit so that the air flows in the direction indicated by the arrows on the body.
- 2. Install the unit as near as possible to the point of use.
- 3. Always depressurise the unit before periodic maintenance and installation.
- 4. Ensure the earth lead is connected to an earth point and verify continuity from each ball valve (item 4) to another known earth point, a resistance of less than 1k ohm should be achieved for dissipation of electrostatic charge.
- 5. An isolation valve is fitted (6) to the inlet of the unit to allow condensate to be drained and for ease of maintenance. Slide to the right towards the regulator to open. Slide to the left to close.
- 6. When reducing the pressure, always turn the regulator below the required pressure and adjust upwards. When assembling the pressure gauge to the unit always tighten by hand. DO NOT USE A SPANNER. (Fig 6).
- 7. To lock the regulator press the adjusting knob down . To release the lock lift the knob up.
- 8. The condensate drain valve on the bottom of the filter can be used semi-automatically or manually.
- a) With the push button in the central position the valve is semi-automatic (i.e. when the filter bowl is depressurised the valve will open allowing the condensate to drain from the bowl). When the bowl is pressurised the drain valve will automatically close.
- b) If necessary, it is possible to drain the condensate while the filter bowl is pressurised. To do this, the simple operation of pushing the valve up will open the drain and release the condensate.
- c) By rotating the button clockwise, the valve becomes locked closed. Drainage is impossible in this position and can only occur when the button is returned to the central position.

Note: To unscrew the bowl from the unit , use a compass key (pin spanner) with 2 mm diameter pins.

Maintenance

Cleaning: The filter element can be removed and cleaned, by removing condensate bowl and unscrewing tie rod.

It is recommended that filter/coalescer/activated carbon elements are replaced periodically i.e. when a drop in pressure is noticeable through the unit or every 6 months.

Ensure earthing of the unit is not affected by maintenance activities , see installation above.

ITW Finishing Systems and Products Ringwood Road, Bournemouth, BH11 9LH, England. Tel. No. (01202) 571111 Telefax No. (01202) 581940, Website address http://www.itweuropeanfinishing.com

ITW Oberflächentechnik GmbH & Co. KG Justus-von-Liebig-Straße 31 63128 Dietzenbach Tel (060 74) 403-1 Telefax: (060 74) 403300 Website address http://www.itw-finishing.de

ITW Surfaces et Finitions 163-171 avenue des Auréats B.P. 1453 26014 VALENCE CEDEX FRANCE Tél. (33) 475-75-27-00 Télex 345 719F DVILBIS Téléfax: (33) 475-75-27-99

ITW Finishing Systems and Products is a Division of ITW Ltd. Reg. Office: Admiral House, St Leonard's Road, Windsor, Berkshire, SL4 3BL, UK Registered in England: No 559693 Vat No 619 5461 24